

FIG. 1




Figure 1 is a perspective view of a portable electronic device 1. The device has a rectangular body with rounded corners. On the front face, there is a large rectangular display screen 38. Above the screen is a small rectangular camera lens 33. To the right of the screen is a speaker grille 31 and a microphone 32. Below the screen are three buttons: a power button 41, a volume button 40, and a navigation button 39. The device is shown from a slightly elevated perspective.

FIG. 5




FIG. 6




FIG. 7




FIG. 8




FIG. 9

